


# RL3822

## ASSEMBLY & INSTALLATION GUIDE

**INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.**

**ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.**



1. Loosen set screws (C), insert both sides of harp (B) into the top opening of harp (D), secure with set screws (C).
2. Remove finial (A) from harp (B), place lamp shade (not included) over the bolt attached on top of harp (B). Screw finial (A) onto the bolt to secure lamp shade to harp (B).
3. Insert light bulb (not included) into the socket.
4. Remove plastic cover (F) from electrical plug (E).
5. Plug lamp into electrical outlet.
6. ADJUSTMENT INSTRUCTIONS
  1. Loosen adjustment knobs (C) at both sides of harp (D).
  2. Adjust harp (B), up or down, to get desired height. Harp (B) should not show under shade when the harp is adjusted correctly.
  3. Carefully tighten knobs (C) on harp (D).

R A L P H L A U R E N