



INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Carefully remove all parts from the carton.
2. Join pole (I), lamp base (J) and base weight (K) together, let the nipple of pole (I) pass through the hole of base weight (K).
3. From the underside of base weight (K), slide the washer (L) over the threaded nipple and then thread nut (M) onto the nipple. Use the wrench (N) to tighten the nut.
4. Thread shade riser (E) into the opening of wire house (F) by turning in a clockwise direction until tight.
5. Remove finial (A) from top of shade riser (E), place shade (B) (packed separately) onto the top of shade riser (E) and secure with finial (A).
6. Insert light bulbs (not included) into sockets.
7. Remove plastic cover (P) from electrical plug (O).
8. Plug lamp into wall outlet.

Adjustment Instructions:

1. Loosen knob (C).
2. Adjust rod (D) up or down to get desired height.
3. Tighten knob (C).

OR

1. Loosen collar (H).
2. For adjust the lamp height, pull lamp rod (G) up or push lamp rod (G) down to the desired height.
3. Tighten collar (H).

\*\*\*Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.