


TOB1720

ASSEMBLY & INSTALLATION GUIDE



INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Carefully remove all parts from the box and remove all plastic covering.
2. Thread Lamp body (J) into Base (L).
3. Adjust the lamp to desired height by pulling upper stem (G)
NOTE: AFTER USE, UNPLUG LAMP TO RAISE OR LOWER THE STEM. TILT LAMP AND KEEP CORD TAUT BY SLIGHTLY PULLING CORD FROM UNDER THE BASE
4. Tighten the stems with handle (H)
5. Insert harp (C) into the two-pronged saddle (F) as shown.
6. Lower harp caps (D) so that they cover the two-pronged saddle (F).
7. Remove finial (A) from harp(C).
8. Place lamp shade (not included) over harp nipple (B) so that the nipple protrudes through the opening.
9. Attach finial (A) to harp nipple (B) and turn clockwise to secure.
10. Insert bulb (not included) into socket (E).
11. Remove red protective plug cover (I) from plug (K).
12. Plug into proper electrical outlet and test fixture.